

Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.


SAVE THESE INSTRUCTIONS


- National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- Follow product label information and instructions.
- · Qualified Personnel with appropriate personal protective equipment must perform all servicing of this product.
- Before wiring to power supply and during servicing, turn off and lock out power at fuse or circuit breaker before service.
- . The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- · Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- · Entire fixture may become extremely hot. Do not touch hot lens or fixture body
- · Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
- · All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty

IMPORTANT LISTINGS AND CERTIFICATIONS


· Suitable for wet locations · Suitable for recessed in ground locations

Proper soil preparation is recommended before installation. See the DIG-IT quide at www.bklighting.com/collaterals/install/digit.pdf for more information.





- Determine Soil Type by referencing Α. DIG-IT Guide.
- B. Dig hole 18" wide and 20" deep.



C. Prep soil according to DIG-IT Guide.

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS




40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 10/15/2021 INS-2373-00

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN.




Housing Installation




 Connect branch conduit connectors (not included) to the junction box using either the threaded conduit entries on the bottom of the junction box or through holes drilled into the sides of the junction box.

Recommend 7/8" hole saw to open threaded $\underline{\bigwedge}$ entry hole.

<u>...</u>




2. Place housing in hole. Align junction box in the path of the conduit trench.




3. Insert four (4) pieces of ½" EMT conduit through the Stability Flange. Hammer into substrate until secure.


 $\underline{\wedge}$ Leave sufficient clearance to elevate housing to finished grade.



4. Raise housing on EMT so housing is flush with finished grade. Use a level to aid in housing installation.




5. When housing is level, tighten screws on Stability Flange to secure housing to EMT. Remove excess EMT as needed.




Pull primary branch circuit wiring into junction box.

6.




7. Per DIG-IT Guide, backfill the gap between the bottom of housing and bottom of hole with sand for drainage.



8. For soil installation: Fill and tamp soil to the appropriate height leaving room for sod, pavers, etc. to be level with the top of the temporary cover.

▲ Soil installation is not drive-over rated.



9. For concrete installation: Fill the hole around the fixture housing to 12" below the finished grade with clean fill dirt and tamp carefully to prevent settling of fixture. Pour concrete and finish as required flush with the top surface of the temporary cover.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



INS-2373-00

B-K LIGHTING


40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com RELEASE DATE 10/15/2021



Installation




1. Remove temporary cover.




Make watertight connections using waterproof wire connectors (included) to leads on the 2. bottom of Patented HydroLock Barrier Plate Assembly. See wiring diagram.

		1	
HOT (BLACK)	_	нот	
		1101	
NEUTRAL (WHITE)	HydroLock	NEUTRAL	Driver
	Plate	GROUND	
GROUND (GREEN)	_		
		l	


WIRING DIAGRAM




Wipe inside of housing where HydroLock plate will sit clean of debris before inserting patented HydroLock plate on to junction box. Align HydroLock plate with pins in housing and seat 3. it firmly in place.



- Turn HydroLock Barrier Plate clockwise 1/4" to 4. lock.
- A Patented HydroLock Barrier Plate must be completely seated to ensure proper seal or water may intrude. This step must be done as stated or you will void your warranty.




Connect transformer assembly to Patented HydroLock Barrier plate with quick disconnect. 5.




6. Lower transformer assembly into HP2 7. Line up transformer plate to posts inside the housing.

B-K LIGHTING



HP2 housing with slots as shown.

40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com



Secure transformer plate into place by tightening the three (3) #6-32 screws against the posts using a 5/64" ball driver. 8.

RELEASE DATE

10/15/2021







INS-2373-00




Standard Installation




9. Connect secondary leads from transformer to OptiLock leads using pre-wired factory quick disconnect.



 Place OptiLock in HP2 housing and align keyhole notch under one of three (3) #8 screw heads. Rotate horizontally to desired aiming position, then tighten two (2) #8 Phillips screws using Phillips screwdriver.




 Aim vertically by turning the thumbscrew on OptiLock assembly.



- 12. Remove any dirt or debris in o-ring groove near top of housing. Place o-ring inside of groove.
- $\underline{\wedge}$ Failure to clean groove of debris will cause fixture to fail and void product warranty.

B-K LIGHTING



- Install faceplate using a 1/8" allen wrench and hand-tighten the faceplate screws in a star pattern to 30 in-lbs. min.
- $\underline{\wedge}$ Do not use a power tool to install screws. Do not exceed 40 in-lbs.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com




INS-2373-00

RELEASE DATE

10/15/2021

HP2 / CO2 LED



Relamping and Optic Replacement








1/8" Allen Wrench


- **Phillips Screwdriver**
- Small Flat Head Screwdriver

Relamping and/or Optic Replacement if Required for LED


5.




Remove faceplate using a 1/8" allen wrench. 1.




2. Space three fingers evenly around the optic and gently rock optic to remove.




3. Use a 5/64" allen wrench to remove two (2) #2-56 screws on LED board. Grasp LED board gently and expose quick disconnect. Disengage LED board from driver assembly.




4. Use Phillips screwdriver to loosen #8-32 Phillips screw on driver bracket on OptiLock. Disconnect driver from fixture via quick disconnect. Replace old driver. Place new driver in bracket, then tighten #8-32 Phillips screw to secure new driver to OptiLock. Reconnect new replacement driver to fixture and to LED board via quick disconnects.




Secure LED board to heatsink by tightening two (2) #2-56 screws on LED board using a 5/64" allen wrench. Carefully snap optics back into tabs on LED board.




- If OptiLock Has Thumbscrew Aim: Aim vertically 6. by turning the thumbscrew on OptiLock assembly.
- 7. If OptiLock Has Tilt Assembly Aim: Aim vertically by turning the #10 Phillips head screw on OptiLock assembly with Phillips screwdriver.



With flat head screw driver rotate Adjust-e-Lume 8. dial to desired lumen output.



- Remove any dirt or debris in o-ring groove near top of housing. Place o-ring inside of groove. Clean lens if needed. 9.
- ▲ Failure to clean groove of debris will cause fixture to fail and void product warranty.



- Install faceplate using a 1/8" allen wrench and hand-tighten the faceplate screws in a star 10. pattern to 30 in-lbs. min.
- Do not use a power tool to install screws. Do not exceed 40 in-lbs.

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS



40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 10/15/2021 INS000012

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN.




Accessories Installation Instructions

Narnin







INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY **TO PERSONS IMPORTANT** SAFETY INSTRUCTIONS

Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing lamp/LED. Lamp/Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure (see diagram/picture). Keep lamp/fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.


SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS


- Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- Follow product label information and instructions.
- Qualified Personnel must perform all servicing or relamping of this product.
- Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker before service.
- The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may
- cause an unsafe condition and void product warranty Do not block light emanating from product in whole or part, as this may cause an unsafe condition.
- Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis
- Entire fixture may become extremely hot. Do not touch hot lens or fixture body. Do not touch the lamp at any time. Use a clean, dry, soft cloth to handle the lamp. Oil from skin may damage the lamp and cause it to rupture
- Replace lamp only with correct wattage and type of lamp marked on fixture label.
- All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.

IMPORTANT LISTINGS AND CERTIFICATIONS


· Suitable for wet locations · Suitable for recessed in ground locations




Rock Guard with Optical Opening




Rock Guard



Half Dome B



Glare Shield B



IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS



40429 Brickyard Drive • Madera, CA 93636 • USA 559,438,5800 • FAX 559,438,5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 10/15/2021 INS-2158-00

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN.




Faceplate Accessories

Instructions Apply To...



Rock Guard with Optical Opening




Rock Guard




Glare Shield B




Half Dome B




- Before installation of faceplate, clean o-ring 1. groove and collar of debris for a proper seal.
- $\underline{\wedge}$ Failure to clean groove of debris will cause fixture to fail and void product warranty.



- Install faceplate using a 1/8" allen wrench and hand-tighten the five (5) #10-24 faceplate 2. screws in a star pattern to 30 in-lbs. min.
- $\underline{\wedge}$ Do not use a power tool to install screws. Do not exceed 40 in-lbs.




3. Using a 7/64" allen wrench, loosen the two (2) #6-32 set screws on the faceplate to allow accessory to rotate freely.



4. Accessory can rotate 360° independently of faceplate.

B-K LIGHTING



When set in final position, tighten two (2) #6-32 set screws using a 7/64" allen wrench. 5.







RELEASE DATE

10/15/2021